



| MI | Code | Ean Code | Pcs |
|------|--------|---------------|-----|
| 750 | 1PM750 | 8020089997758 | 12 |
| 2000 | 1PM002 | 8020089997741 | 6 |
| 5000 | 1PM005 | 8020089997734 | 4 |

Vantaggi

- **Traspirante**
- **Resiste ai raggi UV**
- **Anti sgretolamento**
- **Non forma pellicole**
- **Non ingiallisce**

Advantages

- **Breathable**
- **No crumbling**
- **Non yellowing**
- **UV resistant**
- **Easy maintenance**
- **Non filming**



GLOVE

IMPERMEABILIZZANTE PER TERRAZZI

BALCONI TERRAZZI

Protettivo specifico da applicare su superfici piastrellate per bloccare le infiltrazioni d'acqua. La sua formulazione a bassissima viscosità permette la penetrazione nel supporto tramite le fughe creando una barriera impermeabile che nel tempo evita lo sgretolamento della pavimentazione. Non crea film o pellicole che alterino il colore naturale della superficie. Resiste ai raggi UV e non ingiallisce.

Modo d'uso



Applicare su superfici perfettamente pulite e asciutte (controllare che il supporto sia sano e le piastrelle siano aderenti al massetto prima di eseguire il trattamento). Applicare il prodotto direttamente sul supporto da trattare. Attendere almeno 24 ore poi procedere alla rimozione di eventuali residui di prodotto tramite l'utilizzo di monospazzola e feltro bianco.

Resa


Il consumo indicativo varia da 6-10 m²/litro.

WATER PROOFING FOR TILED BALCONIES AND TERRACES

BALCONIES TERRACES

Specific protective treatment for all external tiled balconies and terraces. Highly recommended for solving problems of water absorption and infiltration. The products low viscosity allows the treatment to penetrate deeply through the joints creating a protective barrier in the substrate avoiding future crumbling and deterioration. Product does not create any surface films non yellowing and maintains the natural colour of the material. UV resistant.

How to use



Apply to perfectly clean and dry surfaces (before proceeding with treatment proceed to check that all surface joints and tiles are completely intact. Apply the product directly to the area to be treated. Allow 24 hours curing time before proceeding to remove any excess surface residue with a white felt pad and mono brush.

Coverage

Indicated coverage varies from 6-10 m²/litre.