



MI	Code	Ean Code	Pcs
750	1PP750	8020089997666	12
2000	1PP002	8020089997659	6
5000	1PP005	8020089997642	4

**Vantaggi**

- **Traspirante**
- **Non ingiallisce**
- **Migliora la manutenzione della superficie**
- **Facile da utilizzare**

**Advantages**

- **Breathable**
- **Non yellowing**
- **UV resistant**
- **Easy maintenance**
- **Easy to use**



# TERRA+

## ANTI MACCHIA PER SUPERFICI INTERNE IN COTTO

### PAVIMENTI IN COTTO COLONNE ARREDAMENTO INTERNO

Trattamento anti macchia specifico per cotto interno, utilizzato nel settore dell'arredamento quali: pavimenti e listelli fatti in cotto classico, rustico o storico. Il prodotto penetra nelle porosità e lascia la superficie protetta dalle varie sostanze macchianti quali: olio, caffè e acqua, etc.

**Modo d'uso**



Applicare su superfici perfettamente pulite e asciutte (per pavimenti già in opera, utilizzare POWER CLEAN per la pulizia preventiva, mentre per le nuove superfici utilizzare C100). Attendere una perfetta asciugatura. Stendere il prodotto in modo uniforme sulla superficie da trattare con rullo, Maialino o Pennellesa. Lasciare asciugare almeno 3 ore prima di effettuare una 2ª applicazione di prodotto. Attendere 24 ore prima di utilizzare la superficie.

**Resa**


Il consumo indicativo varia da 4-12 m<sup>2</sup>/litro.

## ANTI STAIN FOR INTERNAL TERRACOTTA

### TERRACOTTA FLOORS COLUMNS - INTERNAL FURNISHING

Anti stain treatment specific for internal terracotta surfaces such as; floors, tiles and vases in traditional, rustic or antique terracotta. The product penetrates deep inside the surface pores leaving the surface protected against various staining substances such as: oil, coffee and water, etc.

**How to use**



Apply to perfectly dry and clean surfaces (for existing floors, use POWER CLEAN diluted in water using a ratio of 1:30 for surface pre clean; to remove cement and grout film from newly fixed floors, use C100 as directed). Allow the floor to dry completely. Apply the product in a uniform way by brush, roller or spray. Leave to dry for 3 hours before proceeding with the second coat of product. Allow 24 hours for complete drying before using the treated surface.

**Coverage**

Indicated coverage varies from 4-12 m<sup>2</sup>/litre.

